


GET

UN

CENSORED

THE MINI MASSAGER

USER GUIDE



PACKING LIST

- 1 x Massager
- 1 x USB Charging Cable
- 1 x Instructions

TECHNICAL PARAMETERS

- Materials: Silicone, ABS
- Vibration: 6 types, 3 intensities
- Working Voltage: 3.7V
- Power Supply: 300mAh
- Waterproof: IPX6
- Noise: Decibel<60dB
- Duration: >60 minutes (fully charged)

BUTTONS



Press 2 seconds to turn on/off the bullet, Press to shift intensities.



Press to shift modes.

BEFORE USE

1. Charge fully: Plug the USB interface of the charging cable into a charger or computer, then connect the magnetic end to the charging contact point. The indicator light will blink regularly while charging and will stay lit when fully charged.
2. Clean: Rinse with warm water or mild detergent, dry with a towel.

3. Lubricate the product for a more pleasurable experience.


AFTER USE

1. Rinse with warm water and sterilized soap, dry with a towel.
2. Avoid direct sunshine.
3. Keep out of reach of children.

HEALTH AND SAFETY PRECAUTIONS

- Do not charge near water.
- Do not charge if the USB cord appears damaged.
- Do not use other USB cords with your product.
- Do not put the product in the dishwasher or microwave.
- This product is sold as a novelty only. It is not intended for medical applications or any use that has an adverse effect on any function of the body.
- To avoid injury or aggravation of pre-existing physical conditions, this device should not be used on swollen or inflamed areas of skin.
- Wash before and after use. Do not share with other sexual partners.
- Never let children play with this product.
- In case of pregnancy, diabetes or illness, consult your physician before use.
- Do not use if the silicone appears broken or damaged.
- Only use a water-based lubricant with this product.

Indicator light



Magnetic Charging Contact Point

MADE IN CHINA