


GET
UN

CENSORED

THE REMOTE CONTROLLED BALL

USER GUIDE



PACKING LIST

- 1 x Remote Control
- 1x Kegel Ball
- 1 x USB Charging Cable
- 1 x Instructions
- 1x Pouch

TECHNICAL PARAMETERS

Materials: Silicone, ABS

Vibration: 7 types

Remote Control Battery: 70mAh 3.7V Lithium Battery

Kegel Ball Battery: 145mAh 3.7V Lithium Battery

Waterproof: IPX6

Noise: Decibel<60dB

Duration: >60 minutes (fully charged)

BUTTONS



1. Press and hold for 2 seconds to turn on/off.
2. Press to switch modes.
3. Double click to pause.
(In pause mode, the product may automatically turn off after 10 minutes without operation).



Pause/resume motor vibration.



Turn on/switch the motor vibration mode.

BEFORE USE


1. Charge fully: Plug the USB charging cable into the charge port and connect the other end to a computer or USB charger. The indicator light will blink regularly while charging and will stay lit when fully charged.
2. Clean: Rinse with warm water or mild detergent, dry with a towel.
3. Lubricate the product for a more pleasurable experience.

AFTER USE

1. Rinse with warm water and sterilized soap, dry with a towel.
2. Avoid direct sunlight.
3. Keep out of reach of children.

HEALTH AND SAFETY PRECAUTIONS

- Do not charge near water.
- Do not charge if the USB cord appears damaged.
- Do not use other USB cords with your product.
- Do not put the product in the dishwasher or microwave.
- This product is sold as a novelty only. It is not intended for medical applications or any use that has an adverse effect on any function of the body.
- To avoid injury or aggravation of pre-existing physical conditions, this device should not be used on swollen or inflamed areas of skin.
- Wash before and after use. Do not share with other sexual partners.
- Never let children play with this product.
- In case of pregnancy, diabetes or illness, consult your physician before use.
- Do not use if the silicone appears broken or damaged.
- Only use a water-based lubricant with this product.




Remote Control

1. Indicator light
2. Buttons
3. Charge port



Remote control is not waterproof



Kegel Ball

1. Indicator light
2. Charge port
3. Buttons

MADE IN CHINA